

## XVR-01, preparation instructions for ABS body

1



For better visibility, use a marker to draw the line of the cutting area.  
The outside of the line should match the outside of the mark formed by the mold.

2



Roughly precut inside the line with a cutter or scissors.

3



Using a DREMEL-type tool to remove the remaining plastic until the marker line disappears.  
Drill the holes for fixing the body. The marks at the front match to the bumper delivered in the kit. For the rear, you must drill according to your chassis.

4



Glue the lexan roof with LOCTITE or EPOXY type glue, taking care to lightly sand the contact areas.

Disponible en :

ABS 1.5mm

ABS 2mm

Lexan 0.8mm

