

## ESC GL GSC V1.2

Item	Description	1	2	3	4	5	6	7	8	9
#1	<b>Running Mode</b>	1) Forward with Brake (no reverse)	2) Forward / Reverse with Brake	3) Forward /Reverse						
#2	<b>Low Voltage Cutoff (Per Cell)</b>	1) No Protection	2) 2.6V	3) 2.8V	4) 3.0V	5) 3.2V	6) 3.4V			
#3	<b>Over-Heat Protection</b>	1) Enable	2) Disable							
#4	<b>Neutral Range</b>	1) Narrow	2) Normal	3) Wide						
#5	<b>Punch</b>	1) Level 1 (Soft)	2) Level 2	3) Level 3	4) Level 4	5) Level 5	6) Level 6	7) Level 7	8) Level 8	9) Level 9 (Maximum)
#6	<b>Maximum Forward Force</b>	1) 50%	2) 62.5%	3) 75%	4) 87.5%	5) 100%				
#7	<b>Maximum Reverse Force</b>	1) 25%	2) 50%	3) 75%	4) 100%					
#8	<b>Maximum Brake Force</b>	1) Level 1 (Soft)	2) Level 2	3) Level 3	4) Level 4	5) Level 5 (Maximum)				
#9	<b>Drag Brake</b>	1) Off	2) Level 1	3) Level 2	4) Level 3	5. Level 4	6. Level 5	7) Level 6	8) Level 7 (Maximum)	
#10	<b>Brake Punch</b>	1) Drag Brake Force	2) 0%	3) 15%	4) 25%					
#11	<b>Timing</b>	1) None	2) Level 1	3) Level 2	4) Level 3	5. Level 4	6. Level 5	7) Level 6	8) Level 7 (Maximum)	

Default Values